



## **YST BMX-82W**

Instruction: (Please see above drawing.)

- 1. There are 8 items, total 13 pieces in one package.
- 2. All parts are assembled on BB axle already except 2 bolts.
- 3. Disassmbled #7 from #2, then remove "X" part.
- 4. Tighten #1 & 2 with hand.
- 5. Install "Y" part into BB Shell together.
- 6. Install #1,3,4,5 of "X" part into BB Shell.
- 7. Tighten #1 of "X" & "Y" part with Torque Wrench by 350~450kgf-cm.
  8. Put #6 onto #2 and make sure #6 can touch #1 without clearance.
- 9. Tighten #7 onto #2 with Torque Wrench by 350~450kgf-cm.