





BB SHELL

86-92

Instruction: (Please refer to above drawing.)

- 1. There are 7 items, total 9 parts in one package.
- 2. Assemble #1-1 & 2 together. #2 shoule be R side.
- 3. Put #5 into #1-1. #5 is optional for Chain Line adjustment.
- 4. Install "X" into BB Shell by pressing.
- 5. Install #3-1 and Crank Set R into "X".
- 6. Put #6 through BB axle. #6 is optional to fill the gap between the end face of bearing and BB axle.
- 7. Install #4 into #1-2BB then push it till stop to the end face of bearing.

#4 is to convert bearing inner diameter from 24mm to 22mm.

- 8. Install #1-2 into BB Shell by pressing.
- 9. Put #3-2 through BB axle, Then tighten Crank with bolt.